
Explanation
Seismic Design Category
%g
> 125
E
83–125
D2
67–83
D1
50–67
D0
33–50
C
17–33
B
0–17
A
Find map locations by latitude/longitude
1. Select: Tools > Measure > Geospatial Location Tool from the menus above.
2. Right-click inside the map, and then click Find A Location.
3. Type the latitude and longitude values (degrees, minutes, seconds, or decimal) in the two text boxes, and click Find. West longitude values are negative (e.g. -105.4).
If at least one location is available, the location is highlighted with a blue square and the page is centered on the highlighted location.
4. To end the search, right-click inside the map. Then select Hide Location Search, to remove the search boxes.
0 250 500 750 1,000 Miles
0 250 500 750 1,000 Kilometers
125° 120° 115° 110° 105° 100° 95° 90° 85° 80° 75° 70° 65°
50° 45° 40° 35° 30° 25°